

Amplite™ Colorimetric Sphingomyelinase Assay Kit *Blue Color*

Catalog number: 13620
Unit size: 200 Tests

Component	Storage	Amount
Component A: Enzyme Mix	Freeze (<-15 °C), Minimize light exposure	2 bottles (lyophilized powder)
Component B: Sphingomyelin	Freeze (<-15 °C), Minimize light exposure	1 vial (100 µL)
Component C: Amplite™ UltraBlue	Freeze (<-15 °C), Minimize light exposure	1 vial (lyophilized powder)
Component D: SMase Reaction Buffer	Freeze (<-15 °C), Minimize light exposure	1 bottle (10 mL)
Component E: Assay Buffer	Freeze (<-15 °C)	1 bottle (20 mL)
Component F: Sphingomyelinase Standard	Freeze (<-15 °C), Minimize light exposure	0.2 unit (lyophilized powder)
Component G: DMSO	Freeze (<-15 °C)	1 vial (200 µL)

OVERVIEW

Sphingomyelinase (SMase) is an enzyme that is responsible for cleaving sphingomyelin (SM) to phosphocholine and ceramide. Activation of SMases in cells plays an important role in the cellular responses. Five types of sphingomyelinase (SMase) have been identified based on their cation dependence and pH optima of action. They are lysosomal acid SMase, secreted zinc-dependent acid SMase, magnesium-dependent neutral SMase, magnesium-independent neutral SMase, and alkaline SMase. Among the five types, the lysosomal acidic SMase and the magnesium-dependent neutral SMase are considered major candidates for the production of ceramide in the cellular response to stress. Our Amplite™ Colorimetric Sphingomyelinase Assay Kit provides a sensitive method for detecting neutral SMase activity or screening its inhibitors. The kit uses Amplite™ UltraBlue as a colorimetric probe to indirectly quantify the phosphocholine produced from the hydrolysis of sphingomyelin (SM) by sphingomyelinase (SMase). It can be used for measuring the SMase activity in blood, cell extracts or other solutions. The absorbance of light at 655 nm is proportional to the formation of phosphocholine, therefore to the SMase activity. The kit is an optimized "mix and read" assay that is compatible with HTS liquid handling instruments.

AT A GLANCE

Protocol summary

1. Prepare sphingomyelin working solution (50 µL)
2. Add SMase standards and/or SMase test samples (50 µL)
3. Incubate at 37°C for 1 - 2 hours
4. Add sphingomyelinase working solution (50 µL)
5. Incubate at RT for 1 - 2 hours
6. Monitor absorbance at 655 nm

Important Thaw one vial (or bottle) of each kit component at room temperature before starting your experiment.

KEY PARAMETERS

Instrument:	Absorbance microplate reader
Absorbance:	655 nm
Recommended plate:	Clear bottom

PREPARATION OF STOCK SOLUTIONS

Unless otherwise noted, all unused stock solutions should be divided into single-use aliquots and stored at -20 °C after preparation. Avoid repeated freeze-thaw cycles.

1. Sphingomyelinase standard stock solution (10 U/mL):

Add 20 µL of PBS with 0.1% BSA into the vial of Sphingomyelinase Standard (Component F) to make a 10 units/mL sphingomyelinase standard stock solution.

2. Amplite™ UltraBlue stock solution (200X):

Add 100 µL of DMSO (Component G) into the vial of Amplite™ UltraBlue (Component C) to make 200X Amplite™ UltraBlue stock solution.

Note The Amplite™ UltraBlue is unstable in the presence of thiols (such as DTT and 2-mercaptoethanol). The final concentration of DTT or 2-mercaptoethanol in the reaction should be lower than 10 µM. Amplite™ UltraBlue is also unstable at high pH (>8.5). The reactions should be performed at pH 7 - 8. pH 7.4 is recommended for the assay buffer.

PREPARATION OF STANDARD SOLUTION

Sphingomyelinase standard

For convenience, use the Serial Dilution Planner:

<https://www.aatbio.com/tools/serial-dilution/13620>

Add 1 µL of 10 units/mL sphingomyelinase standard stock solution into 1000 µL assay buffer (Component E) to generate a 10 mU/mL sphingomyelinase standard. Take 500 µL of 10 mU/mL sphingomyelinase standard to perform 1:2 serial dilutions to get serially diluted sphingomyelinase standards (SMase7 - SMase1).

Note Diluted sphingomyelinase standard stock solution is unstable and should be used within 4 hours.

PREPARATION OF WORKING SOLUTION

1. Sphingomyelin working solution:

Add 50 µL of Sphingomyelin (Component B) into 5 mL SMase Reaction Buffer (Component D) and mix well.

Note The sphingomyelin working solution should be used promptly.

2. Sphingomyelinase working solution:

Add 5 mL of Assay Buffer (Component E) into the bottle of Enzyme Mix (Component A) and mix well. Add 50 µL of 200X Amplite™ UltraBlue stock solution into the bottle of Enzyme Mix solution before starting the assay.

Note The sphingomyelinase working solution should be used promptly and kept from light; longer storage is likely to cause high assay background. The cloudiness of the mixture is normal; it will not interfere with the assay performance.

SAMPLE EXPERIMENTAL PROTOCOL

Table 1. Layout of sphingomyelinase standards and test samples in a white wall/clear bottom 96-well microplate. SMase = Sphingomyelinase Standards (SMase1 - SMase7, 0.078 to 5 mU/mL), BL = Blank Control, TS = Test Samples.

BL	BL	TS	TS
SMase1	SMase1
SMase2	SMase2
SMase3	SMase3		
SMase4	SMase4		
SMase5	SMase5		
SMase6	SMase6		
SMase7	SMase7		

Table 2. Reagent composition for each well.

Well	Volume	Reagent
SMase1 - SMase7	50 μ L	Serial Dilutions (0.078 to 5 mU/mL)
BL	50 μ L	Assay Buffer
TS	50 μ L	Test Sample

1. Prepare sphingomyelinase standards (SMase), blank controls (BL), and test samples (TS) according to the layout provided in Tables 1 and 2. For a 384-well plate, use 25 μ L of reagent per well instead of 50 μ L.

Note Treat your cells or tissue samples as desired.

2. Add 50 μ L of sphingomyelin working solution to each well of sphingomyelinase standard, blank control, and test samples to make the total assay volume of 100 μ L/well. For a 384-well plate, add 25 μ L of sphingomyelin working solution into each well instead, for a total volume of 50 μ L/well.

3. Incubate the reaction mixture at 37°C for 1 - 2 hours.

4. Add 50 μ L of sphingomyelinase working solution to each well of sphingomyelinase standard, blank control, and test samples to make the total assay volume of 150 μ L/well. For a 384-well plate, add 25 μ L of sphingomyelinase assay working solution into each well instead, for a total volume of 75 μ L/well.

5. Incubate the reaction mixture for 1 - 2 hours at room temperature (protected from light).

6. Monitor the absorbance increase with an absorbance microplate reader at 655 nm.

EXAMPLE DATA ANALYSIS AND FIGURES

The reading (Absorbance (655 nm)) obtained from the blank standard well is used as a negative control. Subtract this value from the other standards' readings to obtain the base-line corrected values. Then, plot the standards' readings to obtain a standard curve and equation. This equation can be used to calculate SMase samples. We recommend using the Online Linear Regression Calculator which can be found at:

<https://www.aatbio.com/tools/linear-logarithmic-semi-log-regression-online-calculator>




Figure 1. Sphingomyelinase dose response was measured on a 96-well white wall/clear bottom plate with Amplitude™ Colorimetric Sphingomyelinase Assay Kit using a SpectraMax microplate reader (Molecular Devices).

DISCLAIMER

AAT Bioquest provides high-quality reagents and materials for research use only. For proper handling of potentially hazardous chemicals, please consult the Safety Data Sheet (SDS) provided for the product. Chemical analysis and/or reverse engineering of any kit or its components is strictly prohibited without written permission from AAT Bioquest. Please call 408-733-1055 or email info@aatbio.com if you have any questions.